



INTRUDER ALARM - MAINTENANCE SCHEDULE

An inspection and test procedure will be undertaken at each scheduled maintenance visit consisting of checks to the following:

- Check that the installation, including type, location and siting of all equipment and devices is in accordance with the System Record (As Fitted)
- Clean all sensor covers.
- Check the satisfactory operation of all detection devices including deliberately operated devices.
- Check all cables and conduit are properly supported, undamaged and showing no signs of wear.
- Check for sound physical fixings of all equipment including loosening or corrosion of supports and fixings.
- Inspect all flexible connections.
- Check and tighten all terminals.
- Check mains and stand-by power supplies including charging rates.
- Check control unit for correct operation.
- Check remote signalling equipment.
- Test remote signalling equipment to ARC or Police Control Room.
- Check all audible warning and alarm devices for correct operation.
- Check the alarm system is fully operational.
- Customer's system logbook filled in.